


1/18

59.0040



095002.010504





FIG. 2A

**FIG. 2B**




FIG. 2C




FIG. 3

MAIN DISPLAY  
410




FIG. 4

PARAMETER  
DISPLAY 510




FIG. 5

612 614

CONFIG. DISPLAY 610

620

630

LOGIN PARAMETERS 650

640

**Configure a New UCCD or Reconfigure an Existing One**

☒ Reconfigure an Existing UCCD ☐ Configure a New Router as a UCCD

**New Router Login**

Username (if Required) \_\_\_\_\_

Password \_\_\_\_\_

Enable Password \_\_\_\_\_

Router's IP Address \_\_\_\_\_

Login

**Router Configuration Info**

Router's New Name

Router's IP Address and Mask **192.168.1.1 w/ 255.255.255.0**

Available Fixed IP addresses **192.168.1.2 thru 192.168.1.50**

**DHCP Server Information**

Enter the IP address of one or more DNS Servers. If more than one, place a space between IP addresses.

Use Default

Enter the IP address of one or more WINS Servers. If more than one, place a space between IP addresses.

Use Default

Configure Cancel Help

FIG. 6




FIG. 7




FIG. 8






FIG. 9




FIG. 10

T06070"2005/2/10




FIG. 11




FIG. 12





FIG. 13



1110

FIG. 14